

Installation Instructions

Hasp & Staple – Safety Pattern / Locking

1. Position hasp and staple in location to check that unit will function as intended.
2. Fasten with screws provided using a no.2 Phillips bit at 1,000 RPM (alternatively you can use a standard screwdriver). Mark holes for screws, drill 2.5mm pilot holes and fasten using screws provided and a Phillips head screwdriver.